

High, Adventure?

If you don't use Akfix High Tack you may say High Adventure...
But with it you may only say

Hi, Adventure!



MS POLYMER
BY KANEKA



Akfix[®]
MASTER OF SOLUTIONS



www.akfix.com info@akfix.com



twitter.com/AkfixSealants
youtube.com/user/AkfixSealants
instagram.com/AkfixSealants
vimeo.com/AkfixSealants

pinterest.com/Akfixsealants
plus.google.com/+AkfixSealantsAdhesives
facebook.com/AkfixSealantsAdhesives
linkedin.com/in/AkfixSealants

High Tack

ALLBOND MS POLYMER

High adhesive strength and initial tack. Suitable for bonding heavy building materials without the use of clamps and/or fixing tape.





Excellent elasticity and very good adhesion strength

No bubble formation

Paintable

No shrinkage

Does not contain solvent, silicone or isocyanate

One Component



It is specially developed as a universal adhesive for bonding various building materials. It is suitable for elastic bonding of panels, profiles and other pieces on the most common substrates such as: stone, concrete, mirrors, glass, plasterboard, **PU, PVC, polyester, plastics, enamel, ceramic, copper, lead, zinc, aluminium, metals, R.V.S., wood, HPL and cement fibre panels etc.**



Waterproof

Does not need primer (preliminary test recommended)

Free from solvent and odorless